

Pro and Classic Security Panel Wiring

WaterCop Interface to Security Panels

Input Signals from Security Panel to Change Valve Position

- Apply momentary dry contact closure between lines 5 and 7 to close the ball valve.
- Apply momentary dry contact closure between lines 6 and 7 to open ball valve.

Output Signals to Security Panel for Valve Position

- Dry contact closure between lines 3 and 4 indicates valve open.
- Dry contact closure between lines 2 and 3 indicates valve closed.



Classic and Pro Interface Contacts

- 7 Brown/White (5VDC)
- 5 Blue/White (to close)
- 6 Green (to open)
- CAT5-E
- 3 Green/White
- 4 Blue 2 Orange

RJ45 Socket

WPC/WPCH Output Signals to Security Panel



To order or for additional information, visit watercop.com or call 800-545-3636.



The proven leader in household leak protection: WaterCop® is there when you're not.