



CLASSIC by DynaQuip

WaterCop Classic Outdoor

This diagram illustrates how to properly wire the WaterCop Classic outdoor actuator to the indoor control unit.

1. Insert the outdoor cable through the lower fitting of the indoor control box.
2. Plug the wires to the indoor wire harness, red/red, black/black and blue/ blue.
3. Reassemble the unit.
4. Refer to owner's manual for installation and operation.

