

THE TERMINAL STRIP AND JUMPER ARE LOCATED ON THE CONTROL BOARD INSIDE THE FRONT COVER OF THE WATERCOP PRO ACTUATOR.
THESE CONTACTS INDICATE VALVE POSITION ONLY.

