

Pro 110VAC Large Valve Ordering Guide

For an indoor or outdoor system with 3" or 4" main water line:

CHOOSE	DESCRIPTION
WCEHSeries	110VAC Industrial Actuator with Valve (See Table 1 below for sizing)
WPC/WPCH	WaterCop PRO Control Panel (attached 20' power cord, 12VDC output; WPCH has HW sensor terminals)
RK110VAC	Relay Kit
WPM or WPM.XT	Choose Number and Type of Wireless Sensor Hubs; with or without ambient temperature sensing
WPSC and Accessories	Choose # of WPSC probes and/ or other options from PRO 'Accessories' Section of Price List

^{*}For outdoor installation extend wires to actuator with 18 gauge outdoor-rated wire and keep RK110VAC indoors with the Control Panel

Table 1

PART #	DESCRIPTION
WCEHH2AATE07	3" Lead Free Brass Valve with 110VAC Industrial Actuator
WCEHH2BATE01	4" Lead Free Brass Valve with 110VAC Industrial Actuator

 $^{^{*}}$ This application requires jumpers between terminals 2 & 4 and 3 & 5 for valve feedback.

* See 'Supplemental Wiring Guide' (Part # 192458) to control ancillary devices such as well pumps, recirculating pumps, second WaterCop Valve, etc.





