


RELAY WIRING DIAGRAM WC CLASSIC TO CONTROL WELL PUMP



WARNING

RELAY COIL WILL BE ENERGIZED
WHEN THE VALVE IS CLOSED

MAKE CONNECTIONS TO THE RELAY COIL
BEFORE ENERGIZING THE ACTUATOR