

Procedure After WaterCop Classic Shuts Off Water

- 1. Get the Sensor Location Log with sensor locations recorded.
- 2. Check the sensor locations to find the wet/ beeping sensor hub.
- 3. See if the beeping sensor has wet or shorted sensor probe/s.
- 4. If the sensor probe is shorted on metal, properly correct it and go to Step 8.
- 5. If the sensor probe is wet, dry the probe and prevent any more leaking.
- 6. If the sensor was alarming for many hours, it's recommended to install fresh batteries.
- 7. If the sensor probe was moved or disturbed, put it back in the correct position. Ensure the sensor probes aren't directly contacting *any* surface.
- 8. Press the OPEN button to turn the water back on.
- * Note: The system won't leave water on until the sensor probe is dry

Installing Company:	Company Phone:
Company Email:	Company Website: